



Housig No	shaft dia	h	a	e	b	u	v	c	w	L	d ₁	d ₂	j	f	g	D	S	Bearing No	Adapter Sleeve	Locating ring	
	d																			Number	QTY
SNU505 TG	20	40	165	130	46	13	20	19	71	67	31,5	39,5	7,5	5	25	52	M10	1205 K	H205	FRM52/5	2
SNU506-605 TG	25	50	185	150	52	13	22	22	87	77	36,5	44,5	7,5	5	32	62	M10	1206 K	H206	FRM62/5	2
SNU507-605 TG	30	50	185	150	52	13	20	22	92	82	46,5	54,5	7,5	5	34	72	M10	1207 K 22207 K	H207 H307	FRM72/8.5 FRM72/5.5	2 2
www.mybearing.eu																					
SNU508-607 TG	35	60	205	170	60	15	20	25	106	85	51,5	59,5	7,5	5	39	80	M12	1208 K 22208 K	H208 H308	FRM80/10.5 FRM80/8	2 2
SNU509 TG	40	60	205	170	60	15	20	25	109	85	56,5	64,5	8,5	5	30	85	M12	1209 K 22209 K	H209 H309	FRM85/5.5 FRM85/7	2 1
SNU510-608 TG	45	60	205	170	60	15	20	25	112	90	62	70,5	8,5	5	41	90	M12	1210 K 22210 K	H210 H310	FRM90/10.5 FRM90/9	2 2
SNU511-609 TG	50	70	255	210	70	18	23	28	127	95	67	75,5	8,5	5	44	100	M16	1211 K 22211 K	H211 H311	FRM100/11.5 FRM100/9.5	2 2

Alle Angaben wurden sorgfältig geprüft, dennoch können wir für Fehler keine Haftung übernehmen

(C) 2015 ICBE InterContinental Bearing Equipment GMBH

www.mybearing.eu

Housig No	shaft dia	h	a	e	b	u	v	c	w	L	d ₁	d ₂	j	f	g	D	S	Bearing No	Adapter Sleeve	Locating ring	
	d																			Number	QTY
SNU512-610 TG	55	70	255	210	70	18	23	30	133	105	72	80,5	8,5	5	48	110	M16	1212 K 22212 K	H212 H312	FRM110/13	2
																				FRM110/10	2
SNU513-611 TG	60	80	275	230	80	18	24	30	148	110	77	85,5	8,5	5	51	120	M16	1213 K 22213 K	H213 H313	FRM120/14	2
																				FRM120/10	2
SNU515-612 TG	65	80	280	230	80	18	26	30	154	115	87	95,5	8,5	5	56	130	M16	1215 K 22215 K	H215 H315	FRM130/15.5	2
																				FRM130/12.5	2
SNU516-613 TG	70	95	315	260	90	22	29	32	175	120	92,5	101	10,5	5	58	140	M20	1216 K 22216 K	H216 H316	FRM140/16	2
																				FRM140/12.5	2
SNU517 TG	75	95	320	260	90	22	30	32	181	125	97,5	106	10,5	5	61	150	M20	1217 K 22217 K	H217 H317	FRM150/16.5	2
																				FRM150/12.5	2
www.mybearing.eu																					
SNU518-615 TG	80	100	345	290	100	22	27	35	192	140	102,5	111	10,5	5	65	160	M20	1218 K 22218 K 23218 K	H218 H318 H2318	FRM160/17.5	2
																				FRM160/12.5	2
																				FRM160/12.5	1
SNU519-616 TG	85	112	345	290	100	22	27	35	209	145	131	141	11,5	6	68	170	M20	1219 K 22219 K	H219 H319	FRM170/18	2
																				FRM170/12.5	2
SNU520-617 TG	90	112	380	320	110	26	32	40	215	160	137,5	147,5	11,5	6	70	180	M24	22220 K 23220 K	H320 H2320	FRM180/12	2
																				FRM180/9.7	1
SNU522-619 TG	100	125	410	350	120	26	32	45	239	175	147,5	157,5	11,5	6	80	200	M24	1222 K 22222 K 23222 K	H222 H322 H2322	FRM200/21	2
																				FRM200/13.5	2
																				FRM200/10.2	1
SNU524-620 TG	110	140	410	350	120	26	32	45	271	185	157,5	167,5	11,5	6	86	215	M24	22224 K 23224 K	H3124 H2324	FRM215/14	2
																				FRM215/10	1
SNU526 TG	115	150	445	380	130	28	35	50	290	190	167,5	177,5	13	6	90	230	M24	22226 K 23226 K	H3126 H2326	FRM230/13	2
																				FRM230/10	1

Alle Angaben wurden sorgfältig geprüft, dennoch können wir für Fehler keine Haftung übernehmen

(C) 2015 ICBE InterContinental Bearing Equipment GMBH

www.mybearing.eu

Housig No	shaft dia	h	a	e	b	u	v	c	w	L	d ₁	d ₂	j	f	g	D	S	Bearing No	Adapter Sleeve	Locating ring	
	d																			Number	QTY
SNU528 TG	125	150	500	420	150	25	42	50	302	205	177,5	187,5	13	6	98	250	M30	22228 K	H3128	FRM250/15	2
																		23228 K	H2328	FRM250/10	1
SNU530 TG	135	160	530	450	160	25	42	60	323	220	192,5	202,5	13,5	6	106	270	M30	22230 K	H3130	FRM270/16.5	2
																		23230 K	H2330	FRM270/10	1
SNU532 TG	140	170	550	470	160	25	42	60	344	235	202,5	212,5	13,5	6	114	290	M30	22232 K	H3132	FRM290/17	2
																		23232 K	H2332	FRM290/10	1

www.mybearing.eu



sales@icbe.net

www.mybearing.eu

www.icbe.net

www.icbe.de

Alle Angaben wurden sorgfältig geprüft, dennoch können wir für Fehler keine Haftung übernehmen

(C) 2015 ICBE InterContinental Bearing Equipment GMBH

www.mybearing.eu